


# RETUNING YOUR DREAMAX RECEIVER



STEP 1  
On the Dreamax Remote press "Menu" button.



STEP 2  
Using the remote control arrow key go down to "Installation"  
Using Remote go to right and select "Manual Scan"



STEP 3  
The screen will ask for a password.  
Using Remote Control number pad key in numbers "0 0 0 0"



STEP 4  
It opens up a Manual Scan Menu



STEP 5  
Click the Round Green button on the Remote Control. This shall open up a small TP Edit window. Select "Add" and Press "OK"



STEP 6  
Manual Scan Menu opens up



STEP 7  
Select TP Freq and enter 1 2 7 0 6



STEP 8  
Go down to Polarization and change it to "Vertical"



STEP 9  
Go down to Symbol Rate and enter 2 2 5 0 0



STEP 10  
Go down Network Search and change it to "ON".  
Press the small Red button (above the arrow keys) on the Remote control



STEP 11  
The STU will scan for the frequencies.  
Please scroll the channels to go to the right channel